



# RED PEPPER MOISTURE METERS

MODEL NO. - ACM- 32443-M





# Red Pepper Moisture **Meters**

We are manufacturers of **Red Pepper Moisture Meter** in India since 1990. We have developed our unique range of red pepper moisture meter, closely working with leading scientific brains of the country along with specialists of various industries, thus ensuring a high level of accuracy, performance and reliability in all our red pepper moisture meters. As a result, all our products have a huge acceptance and usages in various agro industries, food processing industries, agriculture universities, post harvest technology institutes, storage godowns and cold storages across India and abroad.

We specialize in both standard as well as customized moisture meter designed to meet specific demands of general usage customers and research oriented applications.

Over a short period of time Weiber brand have developed as reliable exporters of red pepper moisture meter in India, catering to vast markets in South East Asia, Middle East, Africa and Europe.

Apart from regular exports we are also catering to our domestic market. Our red pepper moisture meter is in great demand in various research stations, agriculture universities, cold storage and various agro based industries.

## TECHNICAL FEATURES

<b>Usage</b>	Different type of Red Pepper
<b>Display</b>	Large Liquid Crystal Display (LCD)
<b>Measuring Range</b>	8% to 27%
<b>Sensitivity</b>	±0.5%
<b>Temperature Correction</b>	Automatic
<b>Power</b>	Normal 1.5 Volt Battery
<b>Repeatability</b>	±0.2%
<b>Dimension</b>	156mm x 66mm x26mm (L X W X D)
<b>Weight (Approx)</b>	750gms



## SEEDS AND MOISTURE RANGE

<b>Melon Seed</b>	3.9% to 11.0%
<b>Water Melon</b>	3.5% to 11.5%
<b>Reddish Seed</b>	5.9% to 14.0%
<b>Cabbage Seed</b>	3.3% to 9.5%
<b>Pumpkin Seed</b>	5.8% to 14.0%

## BASIC FEATURES OF RED PEPPER MOISTURE METER

- Easy Usage
- Compact Design.
- Sturdy Housing.
- High Accuracy.
- High Repeatability
- Large Display (LCD)
- Solid State Micro-Based Technology
- Fast Display Of Results (2 second)
- Automatic Temperature Correction/Compensation
- Long Lasting Battery
- Low Battery Indication Display

## OPERATING PRINCIPLE

Our seed moisture meter works on the principle of measuring the electrical conductivity of a given material, bearing a fixed relation with moisture content of the given material, which is measured using a superior solid state technology and displayed on the screen.



An ISO 9001 : 2208 | ISO 14001 : 2008 | ISO 13485  
WHO: GMP Products | GLP Compliant Products

[www.acmasindia.com](http://www.acmasindia.com) | [www.acmasglobal.com](http://www.acmasglobal.com) | [www.test-chambers.com](http://www.test-chambers.com)

## **ACMAS TECHNOLOGIES PVT. LTD.**

### **CORPORATE OFFICE/ SHOWROOM (INDIA)**

Plot No. 352-353, Sector – 57  
Phase- IV Kundli, Sonapat, Haryana - 131028  
Land Line No.: +91 - 11- 47619688,  
Fax: +91-11-47619788  
E-mail.: [info@acmasindia.com](mailto:info@acmasindia.com)

### **SALES OFFICE (HONG KONG)**

Unit D 28 11/F Wing Tat Comm,Bidg 97, Bonham Strand East,  
Sheung Wan, Hong Kong (PRC)  
Tel.: 0086-13929598046 | 0086- 18922303099  
E-mail.: [hk@acmasindia.com](mailto:hk@acmasindia.com)

### **SALES OFFICE (RUSSIA)**

Inmed Trade Street Ozerkovsky Embankment,  
Unit No 50, Straine- 1, Off- 502, Moscow, Russia  
E-mail.: [info@acmasindia.com](mailto:info@acmasindia.com)  
Tel.: 0049- 79592345 | Email: [russia@acmasindia.com](mailto:russia@acmasindia.com)